

Production



Production

The Production section covers all relevant parameters for the electricity production. Essential are the [Production Units](#) which contain the [Production Start](#), [Power](#) and [Potential P50](#).

The sub sections [Production \(Input\)](#), [Monthly Distribution](#) and [Losses](#) serve as additional refinements of the production parameters.

Section	Input	Calculation	Fimo
Production	<ul style="list-style-type: none">• Project Lifetime• P-Value• Standard Deviation• Safety Reduction (Output)	<ul style="list-style-type: none">• Production calculation	-
Production	<ul style="list-style-type: none">• Monthly Weighting	<ul style="list-style-type: none">• Production calculation	-
Production	<ul style="list-style-type: none">• Production Unit Name• Start Date• Power• Potential P50• Material (Technology = Biomass)	<ul style="list-style-type: none">• Production calculation	-
Production	<ul style="list-style-type: none">• Loss Name• Mode• Value• Start• End• Facilities	<ul style="list-style-type: none">• Production calculation	-