Monthly Distribution

Monthly Distribution

If the production is variable during the year you can enter the monthly share (12 values). The input isn't standardized, which means the percentage of each month is calculated automatically (for example each months share is 1, which implies 1/12 = 8.33% monthly production). The user can enter percentage values or absolute values (for example kWh per month).

Input Field	Description	Value	Influence
Monthly Weighting	Monthly weighting, for example "January: 1, February: 2": In February the production is twice as much as in January. **Example of a Monthly Distribution:** 	Value	Production

Calculation

The Monthly Distribution affects Production calculation.